Sandisk Sansa C200 v2 Series
Audible User Guide

Requirements & Tech Specs

- Windows XP with SP 2 or Vista
- Windows Media Player 11.
- **Audible Formats:** 2 3 4
- **Capacities Available:** 1GB, 2GB
- **Bookmarking:** No
- **Section Navigation:** Yes
- **Variable Playback Speed:** Yes
- **FM Radio:** Yes
- **Video:** No
- **Removable Battery:** Yes

How To's:

A. **Playback:** How do I locate/play Audible content on the device?

1. Press the **Menu** button.
2. Scroll to and select **Music**.
3. Scroll to and select **Audiobooks**.
4. Scroll to and highlight the title you wish to play and press the **Select** button.

B. **Rewind/Fast-Forward:** How do I rewind/fast-forward through my Audible content on the device?

1. **Rewinding:** Press and hold the **Previous/Rewind** button to rewind.
2. **Fast-Forwarding**: Press and hold the **Next/Forward** button to fast forward.

C. **Section Navigation:** How do I use section navigation?

***** *The device must have **Ch. Mode** (chapter mode) turned on.*

1. While the title is playing, press the **Down/Option Menu** button.
2. Scroll down to **Ch. Mode** and select it.
3. Press **Select** button to select *On* (enable).
4. Press **Previous/Rewind** or **Next/Forward** to rewind or skip by section.

D. **Playback Speed:** How do I change the playback speed on the device?

1. While a title is playing, press the **Down/Option Menu** button.
2. Scroll down to **Speed** and press **Next/Forward** to toggle between slow, normal, and fast.

Buttons and Functions

1 – Record	Voice/FM Record Button
2 – Hold/Lock	Factory set to locked position (shows Orange color). Slide to unlock controls. When locked all controls are disabled to prevent accidental activation of controls
3 – MIC	Internal Microphone
4 – Strap Eyelet	Lanyard connection
5 – Earphone Port	Connect earphones here to listen to player
6 – microSD Card Slot	Insert microSD, or Gruvi content cards
7 – Volume Up/Down	To adjust the volume level
8 – Dock Connector Port	Plug the Dock Connector Cable here
9 – Power/Menu	Press and hold to power on or off; press to enter menu
10 – Down/Option Menu	Press to move to next item or to select Option Menu
11 – Previous/Rewind	Press for previous track or move left; press and hold for fast rewind
12 – Display Window	Display the status and information
13 – Select Button	Press to select the highlight item
14 – Up/Play/Pause/Resume	Press to move up one item, pause playing track, or resume playing
15 – Next/Forward	Press for next track or to move right; press and hold to fast forward